

CAPS ACTIVATED Warning

CAPS ACTIVATED

CAPS sequence has been activated.

◆ If message is displayed due to CAPS activation (pulling of CAPS Activation Handle):

1. Refer to [CAPS Activation](#) procedure.

Procedure Complete

• WARNING •

Do not press and hold AP DISC Button if CAPS handle has been pulled; if handle has been pulled, parachute will deploy regardless and pressing AP DISC will prevent the aircraft from adequately slowing prior to deployment.

◆ If message is displayed but CAPS handle is NOT pulled:

- a. AP DISC Button.....PRESS AND HOLD 5 SECONDS

Procedure Complete

• WARNING •

CAPS AP mode will be unavailable for remainder of flight until next power cycle. If CAPS activation is necessary, the pilot must manually reduce airspeed below 135 KIAS and 145 KTAS, whichever is lower, to deploy the parachute.

Refer to [Section 3: Emergency Procedures, "CAPS Activation"](#) procedure.

DOOR OPEN BAGGAGE Warning

DOOR OPEN BAGGAGE

Baggage door is open.

◆ If in flight:

- a. Land as soon as practicable.

Procedure Complete

◆ If on ground:

- a. Verify baggage door is closed.

Procedure Complete