

SHUT DOWN CHECKS

NOTE: Close the HP COCKS after a minimum of 2 minutes at idle RPM, including taxi time.

<i>Both Engines and APU (if installed) Running</i>	
Brakes	PARK
THRUST REVERSERS	OFF
EMERG lights.....	OFF
HP COCKS.....	Close
Fuel PUMPs	OFF
BEACON	OFF
Cabin notices.....	As required
GEN FAIL 1 & 2 annunciators.....	Illuminated
SCREEN HEAT & ALTERNATORS	OFF
ENG CMPTRs.....	OFF - After Engine N ₂ rotation stops.

<i>Both Engines Running and APU (if installed) Not Running</i>	
Brakes	PARK
THRUST REVERSERS	OFF
EMERG lights.....	OFF
MAIN AIR VLV 1	CLOSE
HP COCK 1	Close
L PUMP (fuel).....	OFF
Cabin notices	As required
GEN 1 FAIL annunciator	Illuminated
SCREEN HEAT & ALTERNATORS	OFF
ENG CMPTR 1	OFF - After Engine N ₂ rotation stops.