


MAIN LANDING GEAR ASSEMBLY



DETAIL	PART NAME	DETAIL	PART NAME	DETAIL	PART NAME
No. 1	NUT	No. 17	BOLT	No. 34	O-RING 1101 Series
2	OLEO SPRING ASSY.	18	LOCK WASHER	35	BUSHING
3	OLEO STRUT	19	COTTER PIN	36	SPRING
4	NUT	20	NUT	37	NUT
5	SKIN	21	BRAKE LINE ASSY.	38	BOLT
6	"A" FRAME ASSY.	22	GROMMET	39	PISTON
7	NUT AN365-1032	23	RIVET	40	PLUG (Filler)
8	WASHER AN960-10	24	POP-RIVET	41	ELBOW
9	NUT AN365-1032	25	BEARING	42	BRAKE LINE R.H.
10	WHEEL FAIRING 4037H	26	AXLE NUT	42A	BRAKE LINE L.H.
11	FAIRING MOUNTING	27	COTTER PIN	43	RUBBER WASHER
12	BOLT AN3-12	28	SPACER	44	CYLINDER HEAD
13	BOLT AN526R-10-8	29	BEARING	45	RUBBER CHANNEL
14	BOLT	30	SIRCLIP RING	46	FAIRING
15	NUT	31	CONNECTOR (Piston)	47	SHEET METAL SCREW
16	BOLT	32	BOLT	48	NUT
		33	O-RING 1101 Series	49	SCREW