

AIRPORT DIAGRAM

AL-640 (FAA)

BRADENTON INTL (SRQ)
SARASOTA/BRADENTON, FLORIDA

ATIS 124.375
SARASOTA TOWER* 120.1 256.8
GND CON 121.9 273.6
CLNC DEL 118.25

D

JANUARY 2015
ANNUAL RATE OF CHANGE
0.1° W

TWR 135

FBO

Direction of
landing

ELEV 24

27°24'N

HANGAR

FBO

HS 1

LAHSO

FIRE STATION

HANGAR
Skid marks
beginning past
taxiway A, for
1,130 ft

Final position of
airplane

ELEV 22

RWY 04-22
PCN 53 F/A/W/T
S-120, D-219, 2S-140, 2D-404
RWY 14-32
PCN 47 F/A/X/T
S-118, D-196, 2S-175, 2D-358

TERMINAL

U.S. CUSTOMS &
BORDER PROTECTION
GA FACILITY

NOTE:
TERMINAL RAMP
IS UNCONTROLLED.
DO NOT CALL FOR
PUSH/POWER BACK.
ADVISE GND CON
WHEN READY TO TAXI.

FIELD ELEV 30

27°23'N

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

82°34'W

82°33'W

AIRPORT DIAGRAM

SARASOTA/BRADENTON, FLORIDA
BRADENTON INTL (SRQ)