

BRP-Rotax INSTALLATION MANUAL

If necessary, the carburetor intake should be shielded against effects of the slipstream by a sheet metal shield or air intake box, and the carburetor vent pipes should be routed to a calm air zone or connected to a vent chamber.

Engines supplied with an intake silencer must not be operated unless the carburetor calibration was changed. Consult the engine supplier or manufacturer (in writing) for details. The correct carburetor calibration is also described in the parts list.

Operation in climatic conditions, where carburetor icing is likely to occur, a heating system must be fitted.

No modifications should be made to the carburetor and air intake system without consulting the engine manufacturer (in writing).