

density altitude calculator

To use the calculator, just click the type of units that you will be entering, then enter the altitude, temperature, altimeter setting and dew point. Then click the calculate button.

Elevation	☒ feet	☐ meters	1357
Air Temperature	☐ deg F	☒ deg C	22
Altimeter Setting	☒ inches Hg	☐ mb	30.01
Dew Point	☐ deg F	☒ deg C	16
CalculateReset			

Density Altitude	2622	feet	799	meters
Absolute Pressure	28.568	inches Hg	967.43	mb
Relative Density	92.55	%	92.55	%