


BRP-Powertrain

INSTALLATION MANUAL

Graphic

Bank angle



α	Bank or rotation	F_1	Gravity
β	Bank angle	F_2	Acceleration
		F_r	Result of F_1 and F_2

Fig. 7

07191, 08325