



1 9 6 2
CESSNA
172_c SKY HAWK



**OWNER'S
MANUAL**



Operating Check List

- (3) Mixture - Full rich (unless engine is rough).

CRUISING.

- (1) Engine Speed - 2100 to 2650 RPM.
- (2) Trim Tab - Adjust.
- (3) Mixture - Lean.

LET-DOWN.

- (1) Mixture - Rich.
- (2) Power - As desired.

BEFORE LANDING.

- (1) Fuel Selector - "BOTH ON."
- (2) Mixture - Rich.
- (3) Airspeed - 70 to 80 MPH (flaps up).
- (4) Carburetor Heat - Apply before closing throttle.
- (5) Flaps - As desired (below 100 MPH).
- (6) Airspeed - 65 to 75 MPH (flaps down).
- (7) Trim Tab - Adjust.

NORMAL LANDING.

- (1) Touchdown - Main wheels first.
- (2) Landing Roll - Lower nosewheel gently.
- (3) Braking - Minimum required.

AFTER LANDING.

- (1) Flaps - Up.
- (2) Brakes - Set (at parking area).
- (3) Mixture - Full lean.
- (4) Ignition Switch - "OFF."
- (5) Master Switch - "OFF."