




- | | |
|---------------------------|----------------------------|
| 1 LOWER TORQUE LINK | 23 SHIMS |
| 2 BOLT ASSEMBLY | 24 TANG |
| 3 SHIM WASHERS | 25 PUSH-PULL ROD |
| 4 UPPER TORQUE LINK | 26 BOLT, COUNTER SUNK |
| 5 OLEO STRUT HOUSING | 27 CLEVIS, DRAG LINK |
| 6 ALIGNER GUIDE | 28 UPPER DRAG LINK, LEFT |
| 7 STRUT FILLER VALVE | 29 DOWN LIMIT SWITCH, LATE |
| 8 SPACER WASHERS | 30 CROSS BRACE, DRAG LINK |
| 9 BOLT ASSEMBLY | 31 ATTACHMENT LINK, SPRING |
| 10 STEERING ARM | 32 PIVOT BOLT, DRAG LINK |
| 11 ALIGNER ROLLER | 33 DOWN LOCK SPRINGS |
| 12 BUSHING, STEERING ARM | 34 LOWER DRAG LINK, LEFT |
| 13 STEERING BELLCRANK | 35 LOWER DRAG LINK, RIGHT |
| 14 BOLT ASSEMBLY | 36 SPACER WASHER |
| 15 STEERING ROD, RIGHT | 37 SHIMMY DAMPENER |
| 16 STEERING ROD, LEFT | 38 FORK TUBE |
| 17 LANDING GEAR MOUNT | 39 FORK ASSEMBLY |
| 18 UPPER DRAG LINK, RIGHT | 40 TIRE |
| 19 SPACER WASHER | 41 WHEEL |
| 20 BOLT ASSEMBLY | 42 AXLE NUT |
| 21 SPACER WASHER | |
| 22 BOLT ASSEMBLY | |

