

**Section II
Limitations**

**BEECHCRAFT
Bonanza A35 and B35**

FUEL

Take-off on left main tank.

Standard fuel system: Two 20-gallon tanks in wings. Total 34 gallons usable.

Optional fuel system: Two 20 gallon main tanks in wings and either one 10 gallon or one 20 gallon auxiliary tank installed in the baggage compartment. All of the capacity of the 10 gallon tank is usable. The 20 gallon tank adds 19 gallons usable fuel to the system.

Use auxiliary fuel in level flight only and do not use for take off or landing. Use at least 10 gallons from left main tank before use of auxiliary fuel or right main tank.

When operating fuel selector, feel for detent position.

Do not take off when Fuel Quantity Gages indicate in Yellow Band or with less than 10 gallons in each main tank.

Maximum slip duration: 30 seconds